

# Lapis SALICE


### Index



Lapis for thicker doors - 94° opening	page 4
Lapis - 110° opening	page 6
Lapis with Push system - 94° opening	page 8



Plates page 10



Hinge overall dimensions and size page 11



Assembly and disassembly instructions page 12



Finishes page 15



### **Technical information**

Silentia hinges with cup integrated decelerating system and cover.


Hinges for min. 18 mm thick doors. 15.5 mm deep cup.

94° opening.


Possible drilling distance on the door (K): from 3 to 9 mm.

Adaptable only with longitudinal Domi snap-on mounting plates (BAP).

### Space needed to open the door



	T=	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35
K=3	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.6	2.6	3.5	4.5	5.4	6.4	7.4	8.3	9.3
K=4	<b>A=</b>	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.2	1.9	2.8	3.8	4.7	5.7	6.6	7.6	8.6
K=5	A=	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.2	1.4	2.2	3.1	4.1	5.0	5.9	6.9	7.8
K=6	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.6	0.8	1.0	1.2	1.4	1.7	2.6	3.5	4.4	5.3	6.2	7.2
K=7	A=	0.1	0.2	0.3	0.4	0.5	0.6	0.8	1.0	1.1	1.3	1.6	2.1	3.0	3.8	4.7	5.6	6.5
K=8	A=	0.1	0.2	0.3	0.4	0.5	0.6	0.8	0.9	1.1	1.3	1.6	1.8	2.5	3.3	4.2	5.1	6.0
k=9	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.6	0.8	0.9	1.1	1.3	1.5	1.8	2.1	2.9	3.7	4.6	5.4




K	3	4	5	6	7	8	9
L=	0.0	0.0	0.0	0.0	0.0	0.3	1.3

The above values are calculated on the assumption that the doors have square edges. They are reduced if the doors have radiussed edges.

### **Projection of the door**


Projection of the door from the cabinet side at the max. opening. The figures are based on a straight arm hinge, H=0 mm thickness of mounting plate and K value = 3 mm.



### "C" value

With this formula you can obtain the max. thickness of the moulded door that can be opened without touching adjacent carcase sides, doors or walls, whilst bearing in mind the above L-K-T values.






### Packing

Boxes 300 pcs.
Pallets 7.200 pcs.

Use these formulas to determine the type of hinge arm, the drilling distance "K" and the height of the mounting plate "H" which is necessary to solve each application problem.

Arm 0







**C21BAD9** 

Arm 9





C21BGD9





### **Technical information**

Silentia hinges with cup integrated decelerating system and cover.


Hinges for min. 16 mm thick doors. 13.5 mm deep cup.

110° opening.


Possible drilling distance on the door (K): from 3 to 6 mm.

Adaptable only with longitudinal Domi snap-on mounting plates (BAP).

### Space needed to open the door



	T=	16	17	18	19	20	21	22	23	24	25	26
K=3	<b>A</b> =	0.7	0.9	1.1	1.3	1.6	1.9	2.2	2.6	3.2	4.4	5.7
K=4	<b>A</b> =	0.6	0.8	1.1	1.3	1.6	1.8	2.2	2.5	2.9	3.4	4.7
K=5	A=	0.6	0.8	1.0	1.3	1.5	1.8	2.1	2.4	2.8	3.2	3.7
K=6	A=	0.6	0.8	1.0	1.2	1.5	1.8	2.1	2.4	2.7	3.1	3.6




	T=	16	17	18	19	20	21	22	23	24	25	26
K=3	L=	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.2	0.4	0.6	0.9
K=4	L=	0.0	0.0	0.0	0.3	0.5	0.7	0.9	1.1	1.4	1.6	1.8
K=5	L=	0.6	0.8	1.0	1.2	1.5	1.7	1.9	2.1	2.4	2.6	2.8
K=6	L=	1.5	1.8	2.0	2.2	2.4	2.7	2.9	3.1	3.3	3.6	3.8

The above values are calculated on the assumption that the doors have square edges. They are reduced if the doors have radiussed edges.

### **Projection of the door**


Projection of the door from the cabinet side at the max. opening. The figures are based on a straight arm hinge, H=0 mm thickness of mounting plate and K value = 3 mm.



### "C" value

With this formula you can obtain the max. thickness of the moulded door that can be opened without touching adjacent carcase sides, doors or walls, whilst bearing in mind the above L-K-T values.

C=22.5 + K + A




### Packing

Boxes 300 pcs.
Pallets 7.200 pcs.

Use these formulas to determine the type of hinge arm, the drilling distance "K" and the height of the mounting plate "H" which is necessary to solve each application problem.

Arm 0







C716AD9


Arm 9





C716GD9







### **Technical information**


Push hinges are equipped with a special spring that acts to open the door independently of the release device.

For thick doors up to 35 mm, with special profiles. 15.5 mm deep metal cup. 94° opening.


Possible drilling distance on the door (K): from 3 to 9 mm.

Adaptable only with longitudinal Domi snap-on mounting plates (BAP).

### Space needed to open the door



	T=	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35
K=3	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.6	2.6	3.5	4.5	5.4	6.4	7.4	8.3	9.3
K=4	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.2	1.9	2.8	3.8	4.7	5.7	6.6	7.6	8.6
K=5	<b>A=</b>	0.1	0.2	0.3	0.4	0.5	0.7	0.8	1.0	1.2	1.4	2.2	3.1	4.1	5.0	5.9	6.9	7.8
K=6	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.6	0.8	1.0	1.2	1.4	1.7	2.6	3.5	4.4	5.3	6.2	7.2
K=7	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.6	0.8	1.0	1.1	1.3	1.6	2.1	3.0	3.8	4.7	5.6	6.5
K=8	<b>A</b> =	0.1	0.2	0.3	0.4	0.5	0.6	0.8	0.9	1.1	1.3	1.6	1.8	2.5	3.3	4.2	5.1	6.0
K=9	A=	0.1	0.2	0.3	0.4	0.5	0.6	0.8	0.9	1.1	1.3	1.5	1.8	2.1	2.9	3.7	4.6	5.4




K=	3	4	5	6	7	8	9
L=	0.0	0.0	0.0	0.0	0.0	0.3	1.3

The above values are calculated on the assumption that the doors have square edges. They are reduced if the doors have radiussed edges.


### **Projection of the door**

Projection of the door from the cabinet side at the max. opening. The figures are based on a straight arm hinge, H=0 mm thickness of mounting plate and K value = 3 mm.



### "C" value

With this formula you can obtain the max. thickness of the moulded door that can be opened without touching adjacent carcase sides, doors or walls, whilst bearing in mind the above L-K-T values.




### **Packing**

Boxes 300 pcs.
Pallets 7.200 pcs.

Use these formulas to determine the type of hinge arm, the drilling distance "K" and the height of the mounting plate "H" which is necessary to solve each application problem.

Arm 0







**C21VA99** 

Arm 9





C21VG99



For the complete range of release devices and retaining catches consult Salice general catalogue.

### **Domi snap-on mounting plates**

### **Packing**

Boxes 300 pcs. Pallets 7.200 pcs.

- 21+32 mm drilling.
- Depth and height adjustment by cam.

### **BAP3R**




Die-cast mounting plates. Fixing: wood screw.

B 3.5 DIN 7983.

H= 0 1 2 3 4 5 6






### **BAPGR**



Die-cast mounting plates. Fixing: Euroscrew. Drilling ø5x11.

H= 0 1 2 3 4 5 6




### **BAPMR**



Die-cast mounting plates. Fixing: expanding dowel. Drilling ø10x11.5 mm.

H= 0 1 2 3 4 5 6




### **BAP7R**




Die-cast mounting plates. Fixing: knock-in dowel. Drilling ø10x11.5 mm.


H= 0 1 2 3 4 5 6




Use mounting plates with 6 mm maximum height



Lapis hinge - 0 arm - 0 mounting plate



Lapis hinge - 9 arm - 0 mounting plate



# **Assembly instructions**

After fixing the mounting plate, attach the skirt.



Attached skirt.



Clip the hinge onto the mounting plate.



ATTACHMENT OF THE HINGE ARM COVER



Clip the cover onto the hinge arm.




Press to clip the cover.



ATTACHMENT OF THE DOOR SIDE COVER

Lift the carrier.



Clip the cover onto the carrier.



Half-close the door to ensure that the covers are engaged correctly.





# **Disassembly instructions**

Half-close the door and lift the cover.



Open the door and push the cover firmly in the direction indicated.



Remove the cabinet side cover.



Unclip the hinge from the mounting plate.



Remove the skirt.




**P7A0A09 SATIN CHROME** 

Lapis cabinet side - Arm 0



**P7A0A10 SATIN METAL BLACK** 

Lapis cabinet side - Arm 0



**P7A0A1W SATIN GOLD** 

Lapis cabinet side - Arm 0



P7A0A0C CHAMPAGNE

Lapis cabinet side - Arm 0




**P7A9A09** SATIN CHROME

Lapis cabinet side - Arm 9



P7A9A10 **SATIN METAL BLACK** 

Lapis cabinet side - Arm 9



**P7A9A1W SATIN GOLD** 

Lapis cabinet side - Arm 9



**P7A9A0C** CHAMPAGNE

Lapis cabinet side - Arm 9



P7SXA09SN SATIN CHROME

Lapis door side



P7SXA10SN **SATIN METAL BLACK** 

Lapis door side



**P7SXA1WSN SATIN GOLD** 

Lapis door side



**P7SXA0CSN** CHAMPAGNE

Lapis door side



**P7A0A06 GLOSSY CHROME** 

Lapis cabinet side - Arm 0



**P7A0A0N GLOSSY METAL BLACK** 

Lapis cabinet side - Arm 0



P7A0A0I **STAINLESS STEEL** 

Lapis cabinet side - Arm 0



**P7A0A05 GRAPHITE** 

Lapis cabinet side - Arm 0



**P7A9A06 GLOSSY CHROME** 

Lapis cabinet side - Arm 9



P7A9A0N **GLOSSY METAL BLACK** 

Lapis cabinet side - Arm 9



**P7A9A0I STAINLESS STEEL** 

Lapis cabinet side - Arm 9



P7A9A05 **GRAPHITE** 

Lapis cabinet side - Arm 9



P7SXA06SN **GLOSSY CHROME** 

Lapis door side



**P7SXAONSN GLOSSY METAL BLACK** 

Lapis door side



**P7SXA0ISN STAINLESS STEEL** 

Lapis door side



P7SXA05SN

**GRAPHITE** 

Lapis door side



**P7A0A08 GLOSSY GOLD** 

Lapis cabinet side - Arm 0



**P7A0A07 OLD BRASS** 




**P7A0AA3 BLACK** Lapis cabinet side - Arm 0



**MATT WHITE** Lapis cabinet side - Arm 0

**P7A0A11** 



**P7A9A08 GLOSSY GOLD** 

Lapis cabinet side - Arm 9



P7A9A07 **OLD BRASS** Lapis cabinet side - Arm 9



**P7A9AA3 BLACK** Lapis cabinet side - Arm 9



P7A9A11 **MATT WHITE** Lapis cabinet side - Arm 9



P7SXA08SN **GLOSSY GOLD** 

Lapis door side



P7SXA07SN **OLD BRASS** 

Lapis door side



**P7SXAA3SN BLACK** 

Lapis door side



P7SXA11SN **MATT WHITE** 

Lapis door side



# Note

# Lapis


### **ARTURO SALICE S.p.A.**

VIA PROVINCIALE NOVEDRATESE, 10 22060 NOVEDRATE (COMO) ITALIA TEL. 031 790424 FAX 031 791508 info.salice@salice.com www.salice.com

### **DEUTSCHE SALICE GMBH**

RUDOLF DIESEL STR. 10 POSTFACH 1154 74382 NECKARWESTHEIM TEL. 07133 9807-0 FAX. 07133 9807-16 info.salice@deutschesalice.de www.deutschesalice.de

### **DEUTSCHE SALICE GMBH**

VERKAUFSBÜRO NORD RINGSTRASSE 36/A30 CENTER 32584 LÖHNE TEL. 05731 15608-0 FAX. 05731 15608-10 vknord@deutschesalice.de www.deutschesalice.de

### **SALICE FRANCE S.A.R.L.**

ROUTE DE GOA ZAC LES 3 MOULINS 06600 ANTIBES TEL. 0493 330069 FAX. 0493 330141 info.salice@salicefrance.com www.salicefrance.com

### **SALICE ESPAÑA, S.L.U.**

CALLE COPÉRNICO, 11
POLÍGONO INDUSTRIAL
COLL DE LA MANYA
08403 GRANOLLERS (BARCELONA)
TEL. 938 46 88 61
FAX 938 49 11 97
info.salice@saliceespana.es
www.saliceespana.es

### **SALICE UK LTD.**

KINGFISHER WAY
HINCHINGBROOKE BUSINESS PARK
HUNTINGDON CAMBS PE 29 6FN
TEL. 01480 413831
FAX. 01480 451489
info.salice@saliceuk.co.uk
www.saliceuk.co.uk

### **SALICE AMERICA INC.**

2123 CROWN CENTRE DRIVE CHARLOTTE NC. 28227 TEL. 704 8417810 FAX. 704 8417808 info.salice@saliceamerica.com www.saliceamerica.com

### **SALICE CANADA INC.**

4025 SLADEVIEW CRESCENT UNIT # 7-9 MISSISSAUGA, ONTARIO L5L 5Y1 TEL. 905 8208787 FAX. 905 8207226 info.salice@salicecanada.com www.salicecanada.com

### SALICE CHINA (SHANGHAI) CO. LTD.

1st FLOOR, B1 BLDG 928 MINGZHU ROAD XUJING, QINGPU DISTRICT SHANGHAI 201702 - CHINA Tel. 021 3988 9880 Fax 021 3988 9882 info.salice@salicechina.com www.salicechina.com